



Installation Guide for R900® Adapter Mount Kit for 1.5"-12" Standalone MACH 10® Meter

Kit Part Number: 16230-000

Parts Needed:

Included:

- 1 x R900® Mounting Adapter
- 3 x 10-32 Pan Head Screw
- 3 x 10-32 UNF-2B Hex Nut
- 6 x 10-32 Flat Washer



Not Included:

- 1 x R900 Wall Endpoint with Wall Bracket



Tools Needed:

Adjustable wrench, Phillips Head screwdriver





Step 1

Secure the wall bracket to the R900 Mounting Adapter utilizing two screws, two nuts, and four washers. Tighten $\frac{1}{2}$ turn past hand tight.



Step 2

Secure the R900 endpoint to the R900 wall plate with the single wall plate screw located at the bottom of the endpoint.



Step 3

Secure the R900 Mounting Adapter to the register using one screw, one nut, and two washers, or an optional zip tie (zip tie not included in the R900 Mounting Adapter kit). For the screw, tighten $\frac{1}{2}$ turn past hand tight. On a C&I MACH 10[®] meter, ensure that the endpoint is on the opposite side of the meter from the bleed screw.

Optional: Zip-tie the excess cable in a bundle beneath the endpoint.

